

ENEZIANA


I Istruzioni di montaggio e di assistenza
Specchio circolare

GB Installation and service instructions
Round mirror


F Instructions de montage et d'entretien
Miroir circulaire

D Montage- und Serviceanleitung
Rundspiegel


Dimensioni d'ingombro - Overall dimensions
Dimensions d'encombrement - Maßen




Schema di foratura - Drilling's diagram
Schéma de percement - Löcherschablone




01




02



03



04



BOFFI s.p.a. - Lentate sul Seveso (MB) - via Oberdan, 70
Tel. 0362/534.1 r.a. - Fax 0362/565077